

FIG. 1 is a perspective view taken from above and at one front corner of the audio control panel.

FIG. 2 is a front elevation view;


FIG. 3 is a rear elevation view.

FIG. 4 is a top plan view thereof.

FIG. 5 is a bottom plan view.

FIG. 6 is an end elevation view, the opposite end being a mirror image thereof.

Fig. 1






Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6