

PACER
SLAVE MACHINE INTERFACE DOCUMENTATION
FOR
MCI JH 110

DOCUMENTATION RELEASE : 870413

MACHINE INFORMATION

MACHINE TYPE : MCI JH 110
REMOTES : NONE TESTED
SLAVE LIMITATIONS : NONE
TIME CODE CHANNEL : ANY
HIGH SPEED CODE : NOT APPLICABLE

MINIMUM PROGRAMMABLE RECORD PERIODS

GOOD TIME CODE : 1 FRAMES
TACH ONLY : 1 SECOND

MACHINE BASIC DATA

COMMAND STRUCTURE:

Commands Inactive : +22V
Commands Active : -15V
Command Input Type : TTL
EDIT/LIFTER Command : NO
SHUTTLE Command : NO
Special Features : NONE

TALLY STRUCTURE:

Tally Inactive : +22V
Tally Active : 0V
Tally Drive : TTL
RECORD Tally ? : YES
RUNOUT Tally ? : NO
EDIT Tally ? : NO
Special Features : NONE

TACH FEATURES:

TACH Format : TACH + DIR
TACH Frequency : 8 Hz at 15 ips
Direction Signal : LOW = FORWARDS, HIGH = REVERSE
TACH Output Drive : TRANSISTOR
TACH Pulse Shape : SQUARE

SERVO FEATURES:

Servo Format : FM
FM Frequency : 19.2 KHz
DC Volts Minimum Speed : NA
DC Volts Nominal Speed : NA
DC Volts Maximum Speed : NA
Varispeed Range (%) : +20%
Servo Input Type : TTL
Ext. Servo Cmd. Inactive : NA
Ext. Servo Cmd. Active : NA
Ext. Servo Cmd. Input Type : TTL
PLL Frequency : 38.4 KHz

MACHINE MODIFICATIONS

: NONE REQUIRED

REMARKS

PROGRAMME DETAILS

The programme for the MCI JH 110 is contained in PACER MACHINE EPROM PART NUMBER XPM010, REVISION 2.00.

ATTENTION

As different machine files are contained in alternative machine ROMs do not discard your existing machine ROM when replacing it with the ROM supplied with this kit.

EPROM INSERTION

The machine file EPROM (MACHROM) must be inserted into PACER's main PCB in position IC81. Ensure that the prom orientation is as shown in Figure 1. Incorrect insertion will result in damage to the EPROM.

MACHINE SPECIFIC FILE SELECTION

The required machine file is selected from the MACHROM via the rear panel 16 position HEX switch. The switch setting is confirmed at power up via the time code standard LEDs as follows:

MACHINE	HEX SWITCH POSITION	LED CONFIGURATION			
	8	24	25	29	30
		0	0	0	●

MACHINE SPECIFIC GROUP SELECTION

With Pacer systems which have the extended machine file selection facility (i.e. an 8 position DIL switch located on the rear panel), the DIL switch should be set to the positions shown in Fig. 2.

If your machine does not have the extended Machine Selection Switches then the system should be set up using the Link Configuration diagram supplied with this interface.

NOTE: When using certain types of machines it may be necessary to modify the Link Set Up whether you have extended machine file section or not. A list of these machines is on Appendix A.

MACHINE SPECIFIC COMMANDS & TALLIES

If your Pacer does not have the extended machine file selection facility as shown on Fig. 2, or is a machine listed in Appendix 'A' the specific COMMAND and TALLY structure is selected via PACER main PCB LINKs, See A4/QP/SPD250/030

MACHINE SPECIFIC SERVO SELECTION

If your Pacer does not have the extended machine file selection facility (Fig 2), the required machine specific SERVO is selected via PACER main PCB LINKs, See A4/QP/SPD250/030.

MACHINE FILE
SELECTION SWITCHES




FIGURE 2

APPENDIX A

If this interface is or this Pacer System was previously configured for one of the following machines the Link set up should be checked with the Link configuration diagram supplied with this interface.

Machines which have Command/Talley Links in a different position to standard.

(Pacer Interface SPK 640) Soundcraft 760.

(Pacer Interface SPK 500) Revox PR99.





Figure 1

MODIFICATION	ISSUE	DATE	DRAWN	CHECKED	DRAWING NO.
	1	1.8.86.	JMW		A4/QP/SPD250/030

AUDIO KINETICS
 AUDIO KINETICS (UK) LIMITED
 Kinetic Centre
 Theobald Street
 Borehamwood
 Hertfordshire WD6 4PJ
 England
 Telephone Number 01 953 8118

TITLE
**PACER MACHINE SPECIFIC
 LINK CONFIGURATION FOR
 MCI JH 110**
 © Copyright



CONNECTOR SPECIFICATION	No. of WAYS	TYPE	LOCKING	CABLE SPECIFICATION	No. of WAYS	LENGTH
CONNECTOR 1	25	'D' PLUG	SCREW	CABLE 1	25	6m
CONNECTOR 2	24	BEAU PLUG		CABLE 2	25	15cm
CONNECTOR 3	24	BEAU SOCKET		CABLE 3	4+SC	50cm
CONNECTOR 4	21	BEAU PLUG		CABLE 4	4+SC	50cm
CONNECTOR 5	10	BEAU PLUG		CABLE 5	4+SC	20cm


AUDIO KINETICS (UK) LIMITED
 Kinetic Centre
 Theobald Street
 Borehamwood
 Hertfordshire WD6 4PJ
 Eng. and
 Telephone Number: 01 953 8118

This drawing is the copyright of Audio Kinetics (UK) Limited and must not be copied or reproduced without our written permission.


MOD. No.	ISSUE	DATE	MOD. No.	ISSUE	DATE
			1		10/9/86

TITLE
PACER SLAVE CABLE FOR MCI JH 110 WITH REMOTE CONTROL UNIT

CERT'D.	CHECKED	DRAWN
		JMW
DRAWING No. A3/QP/SPC250/011		




A LINK IS PROVIDED FOR THE GATE SIGNAL. INPUT & OUTPUT FOR 19.2KHz ARE MARKED, OUTPUT GOES TO 10 PIN PLUG. +8V IS DRAWN FROM 10 WAY PLUG PIN 5, & GROUND IS DRAWN FROM PIN 8.



MODIFICATION	ISSUE	DATE	DRAWN	CHECKED	DRAWING NO.
	A	12.8.83	JMW		A4/PI/ACR040/022

AUDIO KINETICS
AUDIO KINETICS (UK) LIMITED
 Kinetic Centre
 Theobald Street
 Borehamwood
 Hertfordshire WD6 4PJ
 England
 Telephone Number 01 953 8118

TITLE
**19.2 KHz PULSE SHAPING BOARD
 ASSEMBLY DIAGRAM**
 ©Copyright



MODIFICATION	ISSUE	DATE	DRAWN	CHECKED	DRAWING NO.
	RELEASE ORDER 18	2	12.8.83	JMW	A4/PI/ACR040/013



AUDIO KINETICS (UK) LIMITED
 Kinetic Centre
 Theobald Street
 Borehamwood
 Hertfordshire WD6 4PJ
 England
 Telephone Number 01 953 8118

TITLE

© Copyright

**19.2KHz PULSE SHAPING BOARD
CIRCUIT DIAGRAM**